

Inhaltsverzeichnis

FAQ - Question and Answers 3
 Q: How to activate outputs with the Standard UDS Library? 3

FAQ - Question and Answers

Q: How to activate outputs with the Standard UDS Library?

- Choose „Swap session mode“ (with doubleclick on the yellow cell) to swich the module into session 03 (diagnostic mode)
- Choose „Store Seckey for this session“. Enter the security code as 5 Byte hexadecimal code
- Choose „Get Sec. Access“. Select Security level 3 and press ok. If everything worked all right, you should get the message „Security Access Level 3 granted“

Now you can switch the outputs

From:

<http://koehlers.de/wiki/> - **Steffen Köhlers Online- Bastelbuch**

Permanent link:

<http://koehlers.de/wiki/doku.php?id=skdsdocu:faq>

Last update: **2010/07/24 14:12**

