

Inhaltsverzeichnis

Embedded Display on a Raspberry Pi	3
<i>Make the System Read-Only</i>	4
<i>Calibrate the Touchscreen</i>	4

Embedded Display on a Raspberry Pi

Install raspian OS lite with the rpi-installer. Use for the settings

- ssh enabled
- use a unique host name for your device
- use the host name as username
- use a unique password. Store username and password at a safe place

After installation and first boot, log in via ssh

Install missing packs

```
sudo apt update && sudo apt upgrade
sudo apt-get install --no-install-recommends xserver-xorg x11-xserver-utils
xinit openbox python3-tk git lightdm
```

For the display driver, follow the instruction from <https://joy-it.net/en/products/RB-TFT3.5>, which are

```
git clone https://github.com/goodtft/LCD-show.git
chmod -R 755 LCD-show
cd LCD-show/
```

Depending on the display size, use

```
sudo ./LCD32-show
```

or

```
sudo ./LCD35-show
```

After reboot and relogin, do

```
sudo raspi-config
```

Go into System Options/ Boot / Auto Login. Select Desktop Autologin to start the window manager at boot

Add the following commands to /etc/xdg/openbox/autostart

```
# Disable any form of screen saver / screen blanking / power management
xset s off
xset s noblank
xset -dpms
```

```
# Allow quitting the X server with CTRL-ATL-Backspace
setxkbmap -option terminate:ctrl_alt_bksp
```

Append the following lines to ~/.bashrc

```
### start the xserver at startup ###  
[[ -z $DISPLAY && $XDG_VTNR -eq 1 ]] && startx -- -nocursor
```

Clone all needed libraries, e.g. pyUMenu

```
cd  
git clone https://github.com/stko/pyUMenu.git  
git clone all_the_others...
```

Create and activate a python virtual environment in your final application directory, here e.g. pyUMenu

```
cd pyUMenu  
python3 -m venv .venv  
source .venv/bin/activate
```

Add the cloned libraries to your virtual environment

```
pip install -e ../my_library  
pip install -e ../all_the_others...
```

Add your program to the openbox autostart by nano \$HOME/.config/openbox/autostart like eg.

```
cd $HOME/pyUMenu  
.venv/bin/python pyumenu_demo.py
```

Make the System Read-Only

After finishing and testing, make the system read-only with `raspi-config`

 **Fix Me!** To be described here

Calibrate the Touchscreen

If needed, the touchscreen can be calibrated

```
sudo apt install xinput-calibrator
```

run it:

```
DISPLAY=:0 xinput_calibrator
```

copy the generated output into

```
sudo nano /etc/X11/xorg.conf.d/99-calibration.conf
```

From:

<http://koehlers.de/wiki/> - **Steffen Köhlers Online- Bastelbuch**

Permanent link:

<http://koehlers.de/wiki/doku.php?id=pc:pidisplay>

Last update: **2024/10/19 07:22**

